



Designing the Next Ultra-Low-Power Always-On Solution

Amol Borkar

Product Marketing Director, IPG TIP
Cadence Design Systems, Inc.

Cadence Tensilica IP: Business Overview and Recent Success



TENSILICA® CUSTOMERS

>40B


Processors
SHIPPED

DSP LICENSING REVENUE

#1 DSP IP
LICENSING
REVENUE

SEMICONDUCTORS


19 of the Top 20
SEMICONDUCTOR
VENDORS
USE TENSILICA



GLOBAL ECOSYSTEM

200+ ECOSYSTEM
PARTNERS

cadence®



Processing and Sensor Trends

Automotive, robotics, drones, mobile, and AR/VR

Automotive



Robotics



Drone



Mobile



AR/VR



Different Types of Sensors: Image Sensors/Lidar/Radar

3D Sensors (TOF), Image Sensors

Large Number of Image Sensors/High FPS/High Resolution

Sensor Fusion

3D Point Cloud/Capture

NEW


Ultra-Low-Power Computer Vision/AI and Always-On Island

Computational Imaging Algorithms

Always-On / Wake-Up Processing



- Protocols or methodologies to “wake up” the device has been around for a long time and is being used in many industries
- Various options for input sources: HDMI, GPIO, Gyroscope...
- Using **microphone** and **ultrasonic sensors** has been prominent in the past few years
 - Proliferated through AI for such usages with TFLm and TinyML
- Interest in using cameras for “visual wake words”
 - People detection, face detection, gestures, etc.
- Emphasis on vision and speech-based processing for embedded/IoT devices (some ultrasonic)



Always-On Primer



- Lightweight algorithms that constantly run or execute on device, typically as a precursor to more accurate (more compute-intensive) algorithms
- Also known as low power or standby mode or AON
- **Applications**



Device Unlock / Authenticate



Video Doorbell




Gesture Control



IoT/Battery Powered Devices


- **Ways to Accomplish This**



Face Detection



Gesture Recognition



Visual Wake Word



Voice Wake Words



Fingerprint



AI


Always-On Requirements




- Basic functionality:
 - Continuously running or actively monitoring on the embedded device
 - Process inputs from cameras, microphones or other sensors in real-time (e.g., 5 – 20 fps)
 - Capable of handling traditional algorithms and lightweight neural networks
 - Ultra-low-power / energy consumption (e.g., <1 mW)
- Introduction of “lite” networks for always-on usages:
 - Designed to run on microcontroller class of devices (e.g., TensorFlow Lite for Micro)
- Common problems in always-on domain
 - Limited availability on public domain (not present in most common model zoos)
 - Expectation that model zoo networks have low energy consumption on always-on processors

Typical Networks	Total MAC count (MAC/Inf)
	Model Zoo Network
Face / Person / Object Detection	30 G
Speech / Voice	200 M
Gesture	10 G


Networks for AON processors are **significantly** smaller than typical model zoo networks



3 Stages of Device Wake / Unlock



3 Stages of Device Wake / Unlock



Focusing on Detection Stage




Lots of ongoing efforts


Emerging markets

Market Classification	Entry-Level / Base	Mid-Range	Premium
Sensor(s)	Ultrasonic, Microphone, Low res. camera	Microphone or Camera or others	Microphone, Camera and others
Typical Applications	Proximity detection	Keyword Spotting, Person / Face detection ...	Keyword Spotting, Person / Face Detection ... IP RE-PURPOSE
Benefits	<ul style="list-style-type: none">✓ Best Area, Power, Energy✓ Simplified algorithms	<ul style="list-style-type: none">✓ Leverage cutting edge AI algorithms✓ Higher resolution for identification	<ul style="list-style-type: none">✓ Area saving with IP repurpose✓ Scalable and future-ready
Limitations	<ul style="list-style-type: none">✗ Not enough res for user identify✗ Limited AI capabilities	<ul style="list-style-type: none">✗ Able to run only one modality (Keyword Spotting, or Face Detection...)	<ul style="list-style-type: none">✗ Increased power consumption

Architectural Considerations: Discrete Data Paths



Architectural Considerations: Combined Data Paths



What Have We Learned So Far? (AKA Requirements)



- There is a need to do always-on processing (AON)
- Area-efficient processor with ultra-low power consumption
 - Operate with extremely small memory footprint i.e., no DDR
- Trending towards discrete or single IP to do multi-modal processing
- Processing inputs from camera, microphone, ultra-sonic sensor, etc.
- Capable of computer vision, AI, speech, sound, FFTs, etc.
- Fortunately, Tensilica® has an answer ...

Selection-Based on Dominant Processing

Sensors



Applications



Dominant Processing



Processor Choice


Audio / Speech
Dominant Processing

Tensilica® HiFi DSP

Image / Camera
Dominant Processing

Tensilica® Vision DSP

Leading Solution for Low-Energy Always-On





Always-On Face Detection (1)




Good
(CPU)


- ✓ CPU **continuously** performs face detection and recognition algorithms
- ✓ CPU recognizes face and unlocks phone
- ✓ **Example:** Phone with CPU only
- X CV+NN algorithms on CPU are not very efficient



Always-On Face Detection (2)




Always-On Face Detection (3)



Always-On Face Detection with Secure Mode



Secure Mode Boundary



TinyML v0.5 Benchmark Comparison



Visual Wake Word







Image Classification



Keyword Spotting



Anomaly Detection



Visual Wake Word







Image Classification



Keyword Spotting



Anomaly Detection



✓ Tensilica® Vision P1 DSP processes vision and audio workloads for always-on


✓ Energy efficient and customizable to run at different frequencies

✓ <1 mW always-on solution

Other Vision Capabilities



Smart Image Sensor



Normal Image
(Pre/Post ISP)

Smart Sensor Processing



Region of
Interest Crop



Metadata



Bounding Box



Segmentation

Foveated Rendering



Headset with pupil camera


cadence®



Cameras capture
pupil images

Tensilica
Vision P1 DSP

Detects
and gaze



✓ Supports all imaging and vision DSP tools and libraries
✓ Supports AI flow of XNNC, NNAPI, TFLm, and more
✓ 100+ model zoo networks supported out of the box

Gaze direction used for
foveated rendering

One Last Thing...



**Come visit Cadence booth
located at 317**

Sources:

MLCommon Tiny Networks Performance

<https://mlcommons.org/en/inference-tiny-05/>

Always-On Market Trend

<https://www.grandviewresearch.com/industry-analysis/light-sensor-market>

2022 Embedded Vision Summit

- **Tensilica® Vision P1 DSP
Always-On FPGA Demo**
 - Visual Wake Word + Keyword Spotting
Demo on same IP
- **Other Vision and AI Demos**



cādence®

© 2022 Cadence Design Systems, Inc. All rights reserved worldwide. Cadence, the Cadence logo, and the other Cadence marks found at <https://www.cadence.com/go/trademarks> are trademarks or registered trademarks of Cadence Design Systems, Inc. Accellera and SystemC are trademarks of Accellera Systems Initiative Inc. All Arm products are registered trademarks or trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. All MIPI specifications are registered trademarks or service marks owned by MIPI Alliance. All PCI-SIG specifications are registered trademarks or trademarks of PCI-SIG. All other trademarks are the property of their respective owners.

